

Get Started

All you need to know to get going.

Samsung GALAXY S5



Welcome!

Thanks for choosing Sprint. This booklet helps you get started with your Sprint Spark™ and HD Voice capable* Samsung Galaxy S® 5.

ReadyNow – For more help in getting up and running with your new phone, take advantage of exclusive **Ready Now** resources at **sprint.com/readynow**. You can even schedule a one-on-one appointment at a Sprint Store near you.

For ongoing support and resources, visit **sprint.com/support**. There, you'll find guides, tutorials, and more to help you get the most out of your phone.

Note: Available applications and services are subject to change at any time.

* The Sprint Spark enhanced LTE network and HD Voice capability are available in select markets. Visit sprint.com/coverage for more information.

Using This Guide

This Get Started guide is designed to help you set up and use your new Samsung Galaxy S 5. It's divided into four sections to help you find the information you need quickly and easily.

- **Get Ready** – page 5 – Find out what you need to do before you use your phone the first time, including charging the battery and activating Sprint service on your phone.
- **Android Basics** – page 8 – Learn some basics about how to move around on your phone, use the home screen, and enter text. If you're familiar with Android™ phones, you can probably skip these pages (although a refresher course never hurt anyone).
- **Use Your Phone** – page 11 – Take advantage of your phone's features and Sprint services, from the basics (making calls) to the more advanced (using Google Play™, Wi-Fi®, and more).
- **Tools & Resources** – page 24 – Find useful tips for your phone and discover resources and other helpful Sprint information. For additional information including the full User Guide, videos, tutorials, and community forums, visit sprint.com/support.

Your Samsung Galaxy S 5



Get Your Phone Ready

Before you start: Visit sprint.com/readynow to learn about transferring contacts, calendars, and more from your old phone.

Install the Battery

1. Use the slot above the power button to remove the battery cover.
2. Align the battery's contacts with those inside the battery compartment and gently press down until the battery is seated.
3. Replace the back cover.

Note: Ensure that back cover is firmly sealed, the gasket around the cover is intact, and the USB cover is in place to maintain water and dust resistance.

Charge the Battery

1. Insert the USB cable into the charger/accessory port.

2. Insert the other end of the cable into the charging head, and then plug the charging head into a standard AC power outlet.

Note: Your phone includes a USB 3.0 cable for higher data transfer speeds when connected to another USB 3.0 device. It also supports USB 2.0 cables (not included).

Note: Connecting the charger improperly may cause serious damage to the device. Any damage caused by misuse is not covered by the warranty.

Turn the Phone On or Off

- Press and hold the Power/Lock key .

Turn the Screen On and Off

- To turn the display screen on or off, press the Power/Lock key . Swipe the screen to unlock it.

Activate Your Phone

Activate Your Phone



If you purchased your phone at a **Sprint Store**, it is probably activated and ready to use.



If you received your phone in the mail, and it is a **new Sprint account** or a **new phone number**, your phone is designed to activate automatically when you first turn it on. You will see a **Hands Free Activation** screen at startup. When it's finished, tap **OK** to continue. To confirm your activation, make a phone call.



If you received your phone in the mail and it is going to be activated on an **existing number (you're swapping phones)**, go to sprint.com/activate and follow the instructions. When you have finished, make a phone call to confirm your activation.

If your phone is still not activated, visit sprint.com/support for assistance. If you do not have access to the Internet, call Sprint Customer Service at **1-888-211-4727** from another phone.

Set Up Your Phone

Once activated, your phone guides you through various setup options, including setting up your Google™ Account.

Complete the Setup Screens

1. When you see the **Welcome** screen, select a language and tap **Start** to begin.
2. Follow the prompts to complete the setup screens. Tap **Skip** to skip any items you don't wish to configure.
 - Set up a **Wi-Fi** connection.
 - Accept **EULA** or other agreements.
 - Use **Tap & Go** to copy Google Accounts, apps, and data from an existing Android device (optional).
 - Sign in to (or set up) a **Google Account**.
 - Sign in to (or set up) a **Samsung** account.
 - Sign in to (or set up) a **Dropbox** account.

3. Enter a device name and tap **Finish**.

Note: You do not need to sign up for a Google Account to use your phone; however, to download content from the Google Play™ store app, you must link your phone to a Google Account.

Note: Your phone may automatically download updates during or after setup, which may require restarting your phone. Follow the prompts to continue.

Your Home Screen

Viewing Your Home Screen

Your phone's Home screen extends horizontally up to seven full screens.

- To display the main (center) Home screen, press  from any screen.
- To view extended screens, swipe the screen left or right.

Status Bar

The status bar at the top of the Home screen lets you quickly see both your phone status (connections, signal strength, battery, GPS) and any current notifications.



Notifications Panel

You can expand the notification area to see more about your notifications.


1. Drag the notifications panel down.
2. Tap a notification to open its app.

Customize Your Home Screen

- To add app shortcuts, tap **Apps** , touch and hold an icon, and drag it to the home screen.
- To change wallpaper or add widgets, touch and hold an empty area on a home screen and tap **Wallpapers** or **Widgets**.

Keys and App Icons

The bottom front of your phone contains three keys: Recent Apps, Home, and Back. Above this row is a row of app icons that are available from every Home screen.



Open Apps

- If an app is on one of your Home screens, just tap it to open it.
- If an app is not available from your Home screen, tap **Apps** , and then tap the app icon. You may have to scroll right or left to find your app.

Open Apps with Multi Window

Multi Window allows you to use two apps on the same screen in separate windows.

1. Drag the Notifications panel down and touch  > **Multi window**  to enable the feature.
2. Touch and hold .
3. Touch and hold an app and drag it to the Home screen, and then touch and hold another app and drag it on top of the first one.

Typing on Your Phone

Your QWERTY Keyboards

Your Samsung Galaxy S 5 offers two onscreen keyboards: Samsung keyboard (default) and Swype™. Select a field that requires text or numbers to display a keyboard.

Note: To switch between keyboards, drag the notifications bar down, touch **Select keyboard**, and touch a keyboard type.

Samsung Keyboard Tips

- Touch **ABC** or **Sym** to change entry type.
- If predictive text is on, words will appear above the keyboard as you type. Touch a word to enter it and move on to the next word.
- If Swiftkey Flow is on, you can enter words by sliding your finger continuously over the keyboard.

Your Keyboard Settings

You can customize your onscreen keyboard settings to suit your needs:

- Tap **Apps**  > **Settings**  > **Language and input** , and tap a keyboard type (**Samsung keyboard** or **Swype**).

Google Voice™ Typing

Use your voice to enter text instead of typing.

1. From any screen where you can enter text, touch the input field to reveal the keyboard.
2. Touch  or  and speak clearly.

Calls

Make a Phone Call

1. If the screen is locked, swipe the screen to unlock it.
2. From home, tap **Phone** .
3. Tap the digits of the number you want to call on the phone keypad. (The number will appear just above the keypad as you enter it. Tap  to delete one or more digits.)
4. Tap .

Answer an Incoming Call

- Drag  to the right on the screen.

Send a Call Directly to Voicemail

- Drag  to the left.

Mute the Ringer on a Call

- Press the volume button on the left side of the phone to mute the ringer.

Voicemail

Set Up Your Voicemail

All unanswered calls are automatically transferred to your voicemail, even if your phone is in use or turned off. You should set up your voicemail and personal greeting as soon as your phone is activated:

1. From home, tap **Apps**  > **Voicemail** .
2. Follow the voice prompts to create your password and record your name and greeting.

Sprint strongly recommends setting a voicemail password.

Retrieve Your Voicemail

1. From home, tap **Apps**  > **Voicemail** .
2. Tap a message to listen to it.

Contacts

Your phone's Contacts app lets you access and manage contacts from a variety of sources, including Google and Corporate email accounts, contacts synced from your computer, and contacts you've entered manually.

Save a Phone Number

1. From home, tap **Phone** .
2. Enter a phone number using the onscreen keypad.
3. Tap **Add to Contacts** > **Create contact**.
4. Select an account for the contact, such as **Google**, **Samsung account**, or **Microsoft Exchange ActiveSync**. Select **Device** to save the contact to your phone only.
5. Tap **Name** and enter a name for the new entry.
6. Tap **Mobile** (default) to select a label such as **Mobile**, **Home**, etc.
7. Add any other information you want to save to the contact and then tap **Save**.

Add a New Entry to Contacts

1. From home, tap **Apps**  > **Contacts** .
2. Tap .
3. Tap any field and enter the name, phone number, and other contact details.
4. Add more data fields or a picture if desired, and tap **SAVE**.

Find a Contact

1. From home, tap **Apps**  > **Contacts** , and then tap **Search**.
2. Enter the first letter or letters of an entry.
3. Tap the contact to display its information.

Messages

Send a Text or Multimedia (MMS) Message

1. From home, tap **Messages** .
2. Tap .
3. Enter a phone number, email address, or contact name in the **Enter recipient** field. (If available, touch a name from the list to finish the entry.)
4. Tap **Enter message** and then type your message.
 - If you want to add an attachment to your message, such as a picture or video, tap .
 - Tap a media type (such as Images, Video, Audio, etc.) and then tap an available album and item.
5. When you're ready to send, tap .

Access Messages

1. From home, tap **Messages** .
2. From the Messages screen, tap the message you want to view.

– or –

1. Open the **Notifications** panel.
2. Tap the message you want to view.

Text and MMS messages are collected in ongoing “conversations,” so when you view a message, you can scroll through the entire history of your messages with that person.

Be a hero. Don't drive distracted.

sprint.com/focusondriving



Focus on driving

Email Setup

Your phone's Email applications let you access and manage multiple email accounts simultaneously in one convenient location.

Set Up a Gmail™ Account

1. From home, tap **Apps**  > **Gmail** .
2. Follow the instructions to set up or sign in to a Gmail account.

Set Up a Standard Email Account

1. From home, tap **Apps**  > **Email** .
2. If another email account is already set up, tap  > **Manage accounts** > .
3. Enter the **Email address** and **Password** for the email account.
4. Tap **Next** and follow the onscreen instructions.
– or –
Tap **Manual setup**, select an account type (POP3 or IMAP), and follow the instructions to configure your account.

Set Up a Microsoft® Exchange ActiveSync® Account

Note: Contact your company's Exchange Server administrator for required sign-in information.

1. From home, tap **Apps**  > **Email** .
2. If another email account is already set up, tap  > **Manage accounts** > .
3. Enter your **Email address** and **Password** information and then tap **Manual setup**.
4. Tap **Microsoft Exchange ActiveSync**.
5. When prompted to provide additional detailed information, scroll down the screen and tap **Next**.
6. Enter a **Domain\user name**, **Password**, and **Exchange server** information.
7. Follow the prompts to set additional options and permissions. Tap **Next** to continue.
8. Identify your new account with a unique name, enter the outgoing name, and then tap **Done**.

Email

Access Email Messages

1. From home, tap **Apps**  > **Email** .
 - To view a different inbox, tap the inbox name at the top of the screen and then tap the inbox you want to view.
2. From the inbox, tap the message you want to view.

Send an Email Message

1. From home, tap **Apps**  > **Email** .
2. If necessary, select the email account you want to use.
3. Tap .
4. Enter an email address in the **To:** field.
5. Enter a subject and a message.
 - To add attachments, tap  (on the top of the screen) and select an attachment.
6. Tap .

Access Gmail Messages

1. From home, tap **Apps**  > **Gmail** .
2. Select the inbox you want to view.
3. Touch a message to view it.

Send a Gmail Message

1. From home, tap **Apps**  > **Gmail** .
2. Tap .
3. Enter an email address or contact name.
4. Enter a subject and a message.
 - To add attachments, tap .
5. Touch  to send the message.

Camera & Video

Take a Picture

1. From home, tap **Camera** .
2. Aim the camera lens at your subject and tap .

View Pictures

1. From home, tap **Apps**  > **Gallery**  to view the Camera folders.
2. Tap a picture and then tap  to explore options. To share a picture, tap it and then, tap  at the top of the screen.

Record a Video

1. From home, tap **Camera** .
2. Aim the lens at your subject, and tap  to begin recording.
3. Tap  to pause or  to stop recording.

View videos

1. From home, tap **Apps**  > **Gallery** .
2. Tap a video and then tap the play icon to view the video.
 - You may be prompted to select a video player to view the video.

Share Pictures and Videos

1. From home, tap **Apps**  > **Gallery** .
2. Tap a picture or video to send.
3. Tap  and select any of several methods such as **Email**, **Bluetooth**, or **Facebook**. Follow the onscreen instructions to send your picture or video clip.

Go Online

1. From home, tap **Internet** . The first time, you may be prompted to enter your wireless phone number.
2. From the Sprint home page, select categories, navigate to websites, read blogs, download content, and more.
 - Tap a category to open it.
 - For more options, tap  from any page.
 - To scroll, slide your finger up or down the page.
 - To zoom in or out, pinch the screen.

Note: Additional browser options, such as Google Chrome™, may also be available on your phone.

Connect to a Wi-Fi Network

When you're in range of an available Wi-Fi network, use your phone's Wi-Fi feature to access the Internet and other data services.

Note: You may already have signed in to Wi-Fi during the phone's setup process.

1. From home, tap **Apps**  > **Settings**  > **Wi-Fi** .
2. Tap the icon next to Wi-Fi and slide to the "ON" position.
3. Tap  and then tap **Scan** to display a list of available networks.
4. Tap a Wi-Fi network to connect. If necessary, enter the security key (password) and tap **Connect**.

Google Play and Google Mobile Services

Google Play is the place to go to find new apps, games, movies, and more for your phone.

Download Apps and Games

1. From home, tap **Apps**  > **Play Store** .
2. The first time you visit the Google Play store app, tap **Accept** to accept the Terms of Service.
3. Browse through featured apps and games, or tap  at the top of the app to start a search.
4. Tap an item to read a description and reviews.
5. Tap **INSTALL** (for free apps) or the price (for paid apps) and follow the onscreen prompts.

Note: You must have a Google Account set up on your phone to purchase and download apps on Google Play.

Google Mobile™ Services

- **Gmail** – The Google mail service. Your Gmail account lets you access many Google-related services as well as Google Play.
- **Google+™ Hangouts™** – Google's instant messaging service. From home, tap **Apps**  > **Hangouts**  to begin using the service.
- **Google Maps™** – The Google location program. From home, tap **Apps**  > **Maps**  to begin using this service.
- **YouTube™** – View and share videos. From home, tap **Apps**  > **YouTube**  to browse through and view available videos. Sign in with your Google Account to upload your own videos.

Bluetooth

Pair and Connect With a Bluetooth®-Capable Device

1. Verify your Bluetooth is turned on. From home, tap **Apps**  > **Settings**  > **Bluetooth**, and then slide the icon to the “ON” position.
2. From the Bluetooth settings page, tap the check box next to your phone’s name to make it discoverable by other devices.
3. Tap  > **Scan**. (You’ll see a list of in-range Bluetooth devices.)
4. Tap a device from the list to initiate pairing.
5. Enter the passkey or PIN code, or verify the shared key, and tap **OK**.
6. The external device will then have to also accept the connection and enter your phone’s PIN code.
7. Once you’re paired with a device, your connection should launch.  shows your current connection status.

Share Contacts, Files, or Pictures Using Bluetooth

1. Open the application containing the file you want to share (for example, from home, tap **Apps**  > **Contacts** ).
2. Locate the file or entry you want to share.
3. You can send pictures and videos directly from the camera or from Gallery, Calendar events, Contacts (as vCards), music tracks, and voice recordings. Not all devices will be able to receive all file types.
4. Depending on the application, tap  > **Bluetooth** or touch and hold the file and select **Share** (or **Send**) > **Bluetooth**.
5. Tap the name of the device to which you’re sending the file.

Facebook, Twitter & More

You can set up and access all your favorite social media apps on the go.

Set Up Social Networking Accounts

Before using your social networking accounts, you may need to download them on the Google Play store app.

1. From home, tap **Apps**  > **Play Store** .
2. Browse or search for the app you want to download, for example **Facebook®**, **Twitter®**, or **Instagram®**.
3. Touch the app and then touch **Install**. Follow the prompts to download and install the app.

Use Social Networking Accounts

1. From home, tap **Apps**  > **Facebook** (or **Twitter**, **Instagram**, etc.).
2. Follow the onscreen instructions to sign into your account, for example, by entering a user name and password.
3. Update your status, post pictures, follow your favorite tweets, and more, all on your Galaxy S 5.

Tip: You can add Home screen widgets for many social networking apps. Touch and hold an empty space, touch **Widgets** and then drag the widget to the empty space.

Sprint Applications

Access additional exclusive Sprint features right from your phone.

Sprint Music Plus

Sprint Music Plus is an all-in-one store and player for songs, ringtones, and ringback tones.

Get Sprint Music Plus

1. From home, tap **Apps**  > **Sprint Music Plus** .
2. Follow the prompts to accept the terms of use and update the app, if required.

Use Sprint Music Plus

- From home, tap **Apps**  > **Sprint Music Plus** .
- Tap  > **Music** (under **Library**) to access all your music.
- Tap **Ringbacks Store**, **Music Store**, or **Ringtones Store** for more options.

Scout™

Scout™ by Telenav is a daily personal navigator that helps you get where you're going.

1. From home, tap **Apps**  > **Scout** .
- The first time you access Scout, you may be taken to the Google Play store. Follow the prompts to install or update the app.
2. Follow the onscreen instructions to access, launch, and use the app.

Sprint Worldwide Wireless Service

With Sprint WorldwideSM Wireless Service, you can make and receive calls, check your email and browse the Web wherever you travel within Sprint's international roaming coverage area.

Activate Sprint Worldwide Service

Before using your phone in global roaming mode, you must activate Sprint Worldwide Service. You can do this online or over the phone.

Activating Online:

- Chat with or email an international support rep by visiting sprint.com/swwsupport.

Activating Over the Phone

- Call Sprint Worldwide Customer support at **1-888-226-7212**.

International Data Roaming

To use Sprint Worldwide Data Services, you will need to have these services activated on your account.

- To activate, call Sprint Worldwide Customer Support at **1-888-226-7212**.

Note: Prior to using your Sprint Worldwide GSM/UMTS Data Services, you must establish and utilize your CDMA data services domestically on the Sprint Network.

Set Network Mode

To roam globally on different types of systems, you may need to select a compatible network mode.

1. From home, tap **Apps**  > **Settings**  > **More networks**  > **Mobile networks** > **Network mode**.
2. Select **CDMA**, **LTE/CDMA**, **GSM/UMTS**, or **Automatic** (recommended).

Once you have activated Sprint Worldwide service and have set your network mode, your phone is designed to enter global roaming mode automatically.

Getting Help

Please call the following numbers if you need assistance with Sprint Worldwide service.

While in the United States:

- Call **1-888-226-7212**.

While traveling outside the United States:

- In GSM mode: touch and hold  and then dial **1-817-698-4199**.
- In CDMA mode: enter the international access code and then dial **1-817-698-4199**.

For more information about international roaming, visit sprint.com/international.

Settings

Explore ways to customize your phone, set permissions, update your phone, and more in the Settings menu.

Accessing Settings

1. From home, tap **Apps**  > **Settings** .

– or –

Drag the notifications bar down and tap **Settings** .

2. Scroll through the settings to find what you want.
 - The settings options are organized into categories: Quick settings, Connections, Device, Personalization, System, and Applications.

- To find what you're looking for, scroll through the list. You can also tap  and enter a search term.
- For more Settings options, tap  to change how Settings are displayed or to customize the Quick settings options.

For detailed information about your phone's settings, please see the User Guide at sprint.com/support.

Battery-Saving Tips

Manage the Display Brightness and Screen Timeout

- From home, tap **Apps**  > **Settings**  > **Display**  > **Brightness** to modify the backlight setting as desired.
- To turn off the screen, press the Power/Lock key . The phone will continue to function.
- Turn on Power saving mode. From home, tap **Apps**  > **Settings**  > **Power saving** . Tap **Power saving mode** or **Ultra power saving mode**, toggle the Off/On switch to On, and then select your power saving mode settings.

Manage Your Phone's Wireless Functions

Disable the Wi-Fi, Bluetooth, and location functions of the phone when you're not using them.

- Use the toggle options in the Notifications panel to turn these off when not in use. Pull down the Notifications panel and tap **Wi-Fi**, **Bluetooth**, or **Location** to toggle these options on or off.

For more useful tips about battery care and safety, see the User Guide at sprint.com/support.

Manage Your Account

Online: sprint.com

- Make a payment, see your bills, enroll in online billing.
- Check minute usage and account balance.
- See or modify the details of your Sprint service plan.
- Get detailed instructions and download content.

From Your Sprint Phone

- Press   to access Sprint Zone, where you can check your account, update your phone, watch video tutorials, or contact Sprint Customer Service.
- Press   to make a payment.
- Press   to check minute usage and account balance.

From Any Other Phone

- Sprint Customer Service:
Dial **1-888-211-4727**
- Business Customer Service:
Dial **1-888-788-4727**

Resources

Resources For Your Phone

- This **Get Started Guide** to get you up and running.
- **Ready Now** – Visit sprint.com/readynow for additional help to get started on your new phone. You'll find more information on basic setup, activation, maximizing your phone's performance, and personalization. Plus, you can even schedule a personalized one-on-one Ready Now appointment at a Sprint Store near you.
- **Online Support** – For ongoing help over the life of your phone, visit sprint.com/support to find videos, tutorials, troubleshooting tips, and the complete User Guide for your Samsung Galaxy S 5.

- **Community** – Visit community.sprint.com to join the discussion about all things Sprint. Here people help each other make the most of their wireless services with tips, forums, blogs, and the latest news.

Sprint Zone

Enhance your Sprint experience. The free Sprint Zone application makes it a snap to manage your account, get tips and tricks for your phone, find recommended apps, and more.

- From home, tap **Apps**  > **Sprint Zone**  to access account services, Sprint news, phone information, suggested applications, troubleshooting, and more.

Sustainability

At Sprint, environmental responsibility is more than talk. We're continuously working to reduce our carbon footprint and decrease our use of natural resources.

So where is my user guide?

We took the full printed user guide out of the box and put it, along with expanded support resources, online for you. Less paper, more and better information. Just visit sprint.com/support from any computer to access your complete user guide and the rest of our support materials.

What else has Sprint been doing?

Plenty. To find out just what we've been up to visit sprint.com/green for more information.



This guide is printed with soy inks and contains 30% post consumer paper.

Survey

We are interested in your initial impressions of this new Sprint phone.

Within two weeks of your phone purchase, please go to the website <http://labs.sprint.com/sprintphonesurvey> to complete a brief survey. Your feedback will help us provide the wireless features and services you want most.

Thank you for choosing Sprint.

Samsung Galaxy S 5

By registering your Galaxy S 5 phone at samsung.com, you are entitled to:

- Premium service through your choice of live chat, email and/or phone
- Access to specialized call center staff to help you get the most from your purchase, including available software, how-to guides and product tips and tricks.
- Extended call center hours
- Galaxy S 5 product user manual

As an owner, you can write a product review, shop for accessories and receive exclusive Samsung offers.

Samsung
GALAXY S 5

SAMSUNG

The services described in this guide may require a subscription to a service plan and/or may incur additional charges. Not all services will work on all phones. See sprint.com/coverage for more details.

Important Privacy Message. This phone is capable of determining its/your geographical location.

To set controls for access and use of your location information by others, from home, tap **Apps**  > **Settings**  > **Location** , tap the Off/On icon so it's in the On position, and then tap **Mode**, and select your location options from the list. Follow any applicable prompts. These settings for the use of location information can be turned on and off. For some applications and services you select, a phone must be turned on and set to allow collection of location information in order to function.

Please be advised that if you use a third party application, the application may collect your personal information or require Sprint to disclose your customer information, including location information (when applicable), to the application provider or some other third party. Sprint's policies do not apply to these third party applications. Please carefully review the application's terms of use and/or the application provider's policies for more information about how the application will collect, access, use or disclose your information before using a third-party application. Terms of use and other policies usually are available on the application provider's website.

Multi Window does not support all applications. This device and related software are not intended for use in the diagnosis of disease or other conditions, or in the cure, mitigation, treatment or prevention of disease.

©2015 Sprint. Sprint and the logo are trademarks of Sprint. Samsung, Galaxy S, and Multi Window are trademarks of Samsung Electronics Co., Ltd. Gmail, Google+, Hangouts, YouTube, Android, Google, Google Maps, Google Mobile Services, Google Voice, and Google Play are trademarks of Google, Inc. Other marks are property of their respective owners. Screen images simulated. Appearance of device may vary.